

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
'		Installation
		Instructions
	LIT3952817	English
	LIT3951578	French
		Use & Care Guide
	LIT3955155	English
	LIT3954821	French
	LIT3954539	Energy Guide
	LIT3955499	Wiring Diagram


Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

	LIT4313896	Manual, Washer Do-It-Yourself
2	8271378	Top White
3	8271380 62750	Spacer, Cabinet To
4 5	357213	Top (4) Nut, Push-In (2) Cabinet
	63424 3954357	White Biscuit
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3976348	Cabinet – Sound Damper
8	3356311	Screw & Washer, Lid Switch (2)
11	3949237	Switch, Lid
12 13	3357011 3351355	Switch, Lid Screw, 10–16 x 1/2
13	3331333	Screw, Lid Hinge Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	91770	Hinge, Lid (R.H.)
17 18	19119 21258	Bumper, Lid Hinge Bearing, Lid
10	21200	Hinge (2)
19		Lid
	3954489	White
20	3954491 358684	Biscuit Strike, Lid Switch
22	9724509	Bumper, Lid (2)
28	3390631	Screw,
		10-16 x 3/8 (5)
31	90016	Clip, Harness
32	3362952	Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)




3

CONTROLS AND REAR PANEL PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)

IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water	16		Cap, End (L.H.)	39		Panel, Console
'	3370300	Inlet Hose (4)		8271365			3955383	
		(1–1/16 x 5/8)		8271368	Biscuit		3955384	Biscuit
2	3400073	Screw, Ground	17	8318201		44		Knob, Timer
3		Hose, Water	18	3952164	Valve, Water		8271345	
		Inlet (2)			Mixing		8271347	
	3949374	Blue Coupler	19	90864	Screw,	45		Dial, Timer
	3949375	Red Coupler			10-24 x 1/2		8271351	
4	9740848		20		Mini-Buzzer		8271370	
5	8318255	Strap, Console (2)	21		Clamp, Hose	47	0074000	Knob, Control
6		Panel, Rear	22	3357328	Hose, Vacuum		8271339	
7		Pad, Rear Panel		074500	Break	40	8271348	
8	3951609	Hose, Drain	23		Clamp, Hose	49	388326	Screw, 8–18 x 1.25
		(4 ft.)	24		Break, Vacuum		00000	(Panel to Top)
	661577	Hose, Drain	25	8519200	Support, Rear	50	62863	Screw, 10–16 x 3/8
		(9 ft.)		004000	Panel	51	0074050	Cap, End (R.H.)
		(Not Included)	26	661606	Capacitor,		8271359	
	3357090	Extension		0000040	Motor Start		8271362	
		Drain Hose	27		Clamp, Hose	55	3390647	
		(21 Inches)	28		Clamp, Hose	-0	2200042	8–18 x 1/2
		(Not Included.)	30	3363366	Clamp, Hose	58	3366913	Clamp, Drain
9	3951702	Timer, Control	31		Clamp, Hose		2240404	Hose Chiefel Code
		(60 Hz.)	32	3951449	Hose, Pump To Tub	59		Shield, Suds
		(Motor Not A		0055000	(Includes #30)	60	3955492	Harness, Wiring
		Service Part)	33	8055003	Člip, Harness			(For Detail See
10	3351614		35	661614	& Pressure Hose	61	2257027	Pages 9 & 10) Nozzle-Drain
11		Screw 8A x 3/8	35	001014	Switch, Water	וט	3357027	Hose
12		Switch, Water Level	26	2400040	Temperature	62	0217040	Drain Hose
13		Bracket, Control	36	3400018	Screw, Timer	02	0317940	Assembly
14		Cord, Power	37	8528333	Mounting			Assembly
15	3952821	Strain Relief,	3/	0020333	Switch, Rotary			
		Power Cord	I			l		



AGITATOR, BASKET AND TUB PARTS For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser
2	358237	Screw & Washer
		(5/16-24 x 1)
3 4	3363003	Clothes Mover
	3951632	Agitator
5	63851	Tub Ring & Gasket
6	3359585	Gasket, Tub Ring
7	3354845	Clip, Agitator
8	3355921	Washer, Agitator
9	3951682	Cam Driven
10	3366877	Dog, Agitator
		Clutch
11	3952374	Bearing-Driven
		Cam
12	21366	Nut, Spanner
13	3951983	Basket & Balance
		Ring
	.=	(Also Order # 14)
14	8522271	Filter Plug
16	63849	
17	389140	Block, Basket
4.0		Drive
18	383727	
19	3347780	Hose, Pressure
00	0054744	Switch
20	3951744	Agitator
	00=4000	(Complete)
22	3951608	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal, Inner Cap
26	3949550	Washer

MACHINE BASE PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit) 2 1 23 13 24 25 15 3 2 4 Illus. Part 17 16 No. No. **DESCRIPTION** 5 1 3400076 Screw, Bracket 3 Mounting (10-32 x 5/8) 2 64067 Bracket, Spring Outer (2) 3 63907 Spring Suspension,(3) 4 3362087 Support & Brake, Tub 18 64065 Bracket, Spring 5 Outer (L.F.) (F) 6 63466 Link, Leveling 6 Mechanism (2) 7 62597 Spring, Leveling Mechanism 8 62837 Pin, Knurled 9 62596 Foot, Rear (2) 3347047 Bearing, 13 Centerpost (2) 357409 Seal, Centerpost (3) 14 388492 Spring, Counterweight 15 62568 Pad, Plate 16 17 3946509 Plate, Suspension (Includes Illus, 16) 26 18 3363660 Pad, Base 3946512 Base Assembly 19 (Includes Illus, 6, 7, 8, 9, 16, 17, 18, & 26) 3359452 Nut, Lock 21 (3/8-16)(2)22 389102 Foot, Front (2) 356934 Seal, Centerpost (2) 23 285203 Centerpost 24 8 21 Bearing Kit (Includes Illus. 9 22 13, 14 & 23) 63134 Ring, Sound

19

25

26


Deadening

Suspension Spring

63806 Retainer,


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)



WIRING HARNESS PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6 7 8	388498 3347812 3352501 90016 3390496	Disconnect (White)	13 14 15 16	3347243 63523 717252	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.) Block, Disconnect (Use Term. 352088) Protector Connector (2–Way) (Use Term.94614) Plug, Terminal (4–Way)	23 24 25 26 27	60687	Connector, Etc Connector, Relay (Use Term.308569) E.T.C. Control Connector (T.P.A.) (3-Circuit) (Lid Switch) (Use Term. 3948619 OR 3948620.) Connector (T.P.A) (3-Circuit) (Pressure Switch)
Ü	002000	Disconnect (Black)			(Power Cord) (Use M3 Screws)			(Use Term.3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613) Or 94614.)	18 19 20		Clip, Harness Block, Disconnect (12–Way) (Timer) (Use Term. 94613)	28 29	3354925 3354926	Block, Connector (Cold Valve) (Use Term.693217) Block, Connector (Hot Valve)
11	353424	Plug, Terminal (3–Way) (Power Cord) (Use Term.94613)	21		(6–Way) (Use Term. 94613) Plug, Terminal (12–Way)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term.3948619
12	62505		22	3369366	(Use Term. 94613 Or 94614.) Timer, Block Disconnect (Black) (Amp) (Use Term. 3369365)			OR 3948620.)

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2G

BRAKE AND DRIVE TUBE PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION				
1	388952	Brake And Drive Tube (Complete)				
2	62658	Ring, Thrust				
3	91939	Seal, Oil				
2 3 4	356427	Seal, Drive Tube				
5	356937	Spacer, Drive				
·		Tube				
6	64027	Tube, Basket				
		Drive (Includes				
		Illus. 3, 4, 5 & 9)				
7	64035	Ring, Retaining				
8	64232	Shoe, Brake				
9	62703	"T" Bearing,				
		Spin Tube				
10	62648	Cap, Brake				
4.4	007000	Spring (2)				
11	387806	Spring, Brake				
12	62909	Sleeve, Brake				
40	62022	Spring Com Broke				
13	63023	Cam, Brake Release				
14	63022					
15	64194	Driver, Brake				
13	04134	Cam				
16	90368	Ring, Retaining				
		- ·				
	FOLLOV	VING PARTS				
	NOT ILLUSTRATED					

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)


GEARCASE PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)

	(Designer Wille) (Bisoun	')		
			1	
	22			
	$\begin{pmatrix} 1 & 1 & 1 \end{pmatrix}$		_	
12		Illus		
3		No.	No.	DESCRIPTION
		1	3360630	Gearcase
		0	005000	(Complete)
	23	2	285202 3349985	Cover, Gearcase Seal, Gearcase
		3	004000	Cover
i 'l	7 — 24	4	285195	Sealer, Gasket
<u> </u>	_ /	_		(.20 Fl. Oz.) (6 ml)
8 \$	25	5	63320	Pinion, Spin (Includes Illus. 25)
	25	6	356427	Seal, Spin
! 9 -	26	· ·		Pinion
		7	389387	Shaft, Agitator
1 10		0	00000	(Complete)
9		8 9	90369 62677	Ring, Retaining (2) Retainer, Spring
	'	10	62676	Spring, Agitate
1 11 - 404		11	63273	Gear, Agitate
1 12		40	00040	(Includes 15 and 29)
- 19		12	62619	Washer, Agitate Gear
13		13	62580	Cam Follower
1 14				(Includes 14)
;	, I A	14	62581	Cam, Agitate
;		15	285509	(Includes 13) Shaft, Agitator
·		13	200000	(Includes 11 and 29)
-		16	62618	Washer, Cam Thrust
!		17	16018	Bearing, Thrust
!		18 19	85529 389230	Ball, Bearing Bottom and Pinion,
	!	13	303230	Gearcase
15	27	21	285352	Seal, Thrust Plug
		22	3351614	Screw, Gearcase
				Cover, Mounting (8) (10–24 x 3/8)
ı 16	28	23	3362552	Ring, Retaining
		24	285735	Washer Kit,
29		0.5	00570	Thrust
8		25 26	62570 388253	Gear, Spin Neutral Assembly
1 1 7 L — — — — — — — — — — — — — — — — — —	i	20 27	3349296	Rack, Connecting
		28	62621	Actuator, Shift
18		29	388815	Washer,
				Intermediate
· · · · · · · · · · · · · · · · · · ·	men			
21	> (
121				
	4			
l	– – – → GC–215–C I			
L				

WATER SYSTEM PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit
6 7	65349 367031	(Not Included) Clamp, Hose Drain Protector (Not Included)

MISCELLANEOUS PARTS

For Models: LSN1000KQ0, LSN1000KT0 (Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous
_		Parts Bag
2	3976300	Washer, Inlet
		Hose
3	2266012	(1-1/16 x 5/8) (4) Clamp, Hose
4		Nut, Lock
4	3333432	(3/8–16)
5	3366913	Clamp, Hose
6		Foot, Front (2)
-		(-)

OPTIONAL PARTS (NOT INCLUDED)

Illus. Part No. No. DESCRIPTION		Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH-UP (1/2oz.) 72017 White 4392899 Biscuit	OIL 3	350572	Oil, Gearcase (16 Oz.)	SEAL		5 Sealer, Gasket (.20 Fl. Oz.) (6 ml)
PAINT, PRESSURIZED SPRAY (12 oz.) 350938 Primer, Gray 350930 White 4392901 Biscuit PAINT, BULK (1 qt.) 799344 White (Uncut) 4392900 Biscuit (Uncut)	LUBRI 2		Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)		ESSOR 36703 ²	5 Shipping Kit